


LONG BOARD SWING




LONG BOARD SWING INSTRUCTIONS


The tool & parts list



1×



2×



2×



2×



2×



8×




4×



1×

Assembly instructions


Note: The white foam is part of the product and must not be removed!



Here's the
Velcro opening.


Place flat with the back up.

step1




Open the Velcro opening and
insert the curved tube with foam.

step2



Open the Velcro opening and
insert the straight tube with foam.


step3




Insert the end of the straight
tube into the elbow to align the
round holes.

step4

thread a washer onto the
eye bolt at the top end of
the swing rope, pass it
through the swing's
round hole, then
thread another
washer and a nut,
and tighten the nut



step5



step6

HOW TO USE YOUR LONG BOARD SWING

BEFORE HANGING, BE SAFE HAVE FUN

- Your swing area should be over soft, flat terrain and free of obstacles. **DO NOT INSTALL THE SWING OVER CONCRETE, ASPHALT OR ANY OTHER HARD SURFACE.** Trust us on this one.
- Don't pile on too many kids, the swing is built for 1 or 2 with a max weight of 130kgs.
- Adult supervision is advised at all times during outdoor play.

SETUP INSTRUCTIONS

- Take swing out of the box. Check you have all parts and tools as shown
- First, place the swing cover flat with its back facing up, open the Velcro opening, then insert the curved tubes with foam into both ends of the cover through the Velcro opening respectively.
Next, insert the straight tubes with foam into both cover sides through the opening, and insert their ends into the curved tubes to align the round holes.
Finally, thread a washer onto the eye bolt at the top end of the swing rope, pass it through the swing's round hole, then thread another washer and a nut, and tighten the nut. Repeat this step until all parts of the swing rope are fixed.
Please note - make sure the bolts are tightened properly underneath the swing so that the connections are secure before use.

ASSEMBLY ADVICE

- The assembly of the product must be done carefully and by an able-bodied adult. If in any doubt, ask a technically qualified person.
- Make sure the four pole sections onto flat level after assembly , then tighten with bolts.

WARNING!

- The disassembled product may contain small parts which pose a choking hazard to children under 3
- Only for the domestic use.
- Be careful during assembly of the tube sections, as there is a risk of pinching your skin when the tubes are inserted into one another.
- Children should supervised by an adult at all times.

IMPORTANT:

- This product may contain sharp points and small parts prior to assembly.
- The owner's manual contains safety, assembly, use instructions. This product must be assembled by an adult who has read and understood these instructions. Keep the packaging away from children and dispose of all packaging before use.
- For the installer and your children's safety, it is important to fully read and understand the instructions and safety hazards before commencing the assembly of the product.
- This Nest Swing is designed for Children 3-14 years old and for the limit weight of 130kgs.
- To prolong the life of your product, remove from frame when not in use and during winter months

GENERAL SAFETY

- **This product is intended for outdoor, domestic use only.**
- **This product may only be used with adult supervision at all times.**
- **WARNING! No eating while using the product.**
- **WARNING! Do not jump on the swing .**
- **The packaging material is not suitable for children due to choking and suffocation hazards.**

RISK OF INJURIES

- **Do not use the product if it is damaged or defective. If it is damaged or defective, please contact a qualified technician. Funky monkey Bars customer service 1300912198.**
- **Check the product before each use. Defective parts must be changed immediately as they can impair the function and the safety of the product.**
- **Do not place any objects or body parts in the product's openings.**

PRODUCT DAMAGE

- **Do not make alterations to the product. Only use original spare parts. Qualified technicians should only carry out repairs – improper repairs can lead to danger for the user. Use this product only as described in this manual.**